



# Overpack with screw lid 360 Litre Maintenance Spill Kit

SK-M360OP



Spill kit | 360 Litre | Maintenance | Overpack with screw lid

**Basis weight:** -

**Absorbency:** 360 Litres | 79.2 US Gallons of oil\*\*  
- Litres | - US Gallons of water\*\*

**Base Fibre:** Cellulose




**Coldform™**

Product Code	Colour	Weight	Format	Size cm(inches)	Recycled Content	Units/Case	Weight/Case™	LTL/Pallet	FTL/Pallet
Maintenance									
SK-M360OP	Grey	286 gsm	Spill Kit	-	60%*	1	-	-	-

## 360 Litre Spill Kit in an Overpack


Spun-bond top cover  
Coldform™ core



### 360 Litre Overpack

#### Spill Kits contain:

- 200 x heavy weight pads
- 10 x 1.2 m socks
- 10 x 46 cm x 46 cm pillows
- 20 x waste disposal bag and ties



*This product is in an Maintenance format*

#### Description

Designed to accommodate a standard 205 litre drum, the tough polypropylene lid with large gauge screw lid is designed to be placed over punctured drum then inverted to minimise the escaping liquid. This spill kits feature a combination of pads, socks and pillows that will contain and recover a standard 205 litre drum's contents, as well as the basic equipment needed to handle the clean up process. These kits can be adapted or have branding added. Please note the PPE shown is not included but can be specified if required.

This kit contain Coldform™ cellulose absorbents. The Maintenance Coldform™ pads are unique in the fact that one side is no lint, and very durable and the other side is soft and absorbent.

#### Notes

- Fire retardant as per ASTM 726
- Ensure that disposal of these sorbents complies with all regulations.

\* Basis weights and recycled content are ± 5%

\*\* Measures a case/bale using ASTM 726 (long test) with medium viscosity oil and tap water. Statistical average derived from real time production QC data.

\*\*\* Weight per case ± 0.5 kg/lbs.

#### Compliance

Related Regulations	Description
29CFR 1910.22(a)(2)	"The floor of every workroom shall be maintained in a clean and, so far as possible, a dry condition."
29CFR 1910.120(j)(1)(vii)	"...suitable quantities of proper absorbents shall be kept available and used in areas where spills, leaks or ruptures may occur."
29CFR 1910.107(g)(2)	"All spraying areas shall be kept as free from the accumulation of deposits of combustible residues as practical."